



Description of the main icons

ICONS	DESCRIPTION
	Transmitting a one-way call
	Receiving a one-way call
	Status message/s received
	Battery bar icon
	Signal strength bar icon
	Loudspeaker in use
	Loudspeaker and earpiece not in use
	Top microphone selected
	Speakers and tones muted
	Keypad locked
	Text message/s received
	Scanning activated
	Air interface encryption not in use
	Transmission barring active
	Connection to network lost, limited services available
	GPS receiver on


This document is the property of Cassidian Finland Oy and should not be copied or circulated without permission.
www.cassidian.com



Getting started

Install the battery

- 1 Slide the battery in the radio body
- 2 Press the bottom part of the battery into its position until it clicks



Install the antenna

Turn the antenna clockwise in its dedicated slot on top of the terminal

Switch the radio on

- 1 Press and hold the power on/off switch
- 2 If the radio asks for a phone or a security code, enter these and select **OK**

Note: the initial phone code is 1234

Note: this Quick Guide aims at helping users get started with their radio. The detailed information on radio usage is available in the full User Guide at <https://pmronline.cassidian.com>.

Making and receiving calls (1/2)

Make a call

Group call

- 1 Press
- 2 Scroll to the desired folder
- 3 Choose **Select**
- 4 Turn the group selector until you reach the desired group
- 5 Press and hold the PTT key
- 6 Start speaking when a short tone is played

Express call

- 1 To a TETRA number: type the number
To a phone number: type the number, press and scroll to *Phone*
- 2 Press and hold the PTT key

Phone call

- 1 Enter the area code and phone number
- 2 Press
- 3 Scroll to the relevant number type among *Private*, *Abbr. number*, *Phone*, or *Office ext. no.*
- 4 Press

Making and receiving calls (2/2)

Red key call

Press and hold the red key call button to call the predefined destination

Call in direct mode

- 1 Select **Menu** → *Settings* → *Phone settings* → *Active mode* → *Direct*
- 2 Turn the group selector until you reach the desired channel and press the back key to select the relevant group
or
enter the recipient's number
- 3 Press and hold the PTT key

Respond to a call

Phone call

Press

Group or Express call

- 1 Press and hold the PTT key
- 2 Start speaking when a short tone is played

Sending text messages

Send a status message

- 1 Press
- 2 Scroll to the relevant status message
- 3 Select **OK**
- 4 Enter the phone number or search for the recipient
- 5 Select **OK**
- 6 Scroll to the relevant number type
- 7 Select **Send**

Send a text message

- 1 Press
- 2 Write the message
- 3 Select **Send**
- 4 Enter the phone number or search for the recipient
- 5 Select **OK**
- 6 Scroll to the relevant number type
- 7 Select **Send**

Note: your organisation may predefine different functions for the and key